

Product: Sender	Description CYLINDER HEAD TEMPERATURE	Date Jan 04
Type: Electrical		Issue 1

Sender Testing

- 1) Turn voltmeter to millivolts (mV)
- 2) Hook the red lead of the voltmeter to the black lead of the thermocouple.
- 3) Take the black lead of the voltmeter to the red lead of the thermocouple.
- 4) Take a flame to heat up the thermocouple at the compression ring.
- 5) The voltmeter should start to rise. If not the thermocouple is bad.